MANUFACTURERS NOTE

When using a non tank mounted diaphragm compressor. A small bleeder hole must be drilled in the 1/4" pipe adaptor to prevent back pressure. Drill hole on flat surface just behind the taper, using a number 72 drill. If you should change to a tank mounted compressor the bleeder hole on the 1/4" adaptor must first be sealed. Masking or duct tape (not included) may be used or a small drop of solder.